

|                |              |                   |              |                   |
|----------------|--------------|-------------------|--------------|-------------------|
| <b>NITRILE</b> | <b>GREEN</b> | <b>REF: RNF15</b> | <b>S-XXL</b> | <b>FLOCKLINED</b> |
|----------------|--------------|-------------------|--------------|-------------------|

Resistant green glove, available in blue, flocklined. Premium Grade acrylonitrile Butadiene Rubber. Excellent resistance against aromatic and petroleum solvents and animal fats. It offers protection against to hight variety of chemicals and against solvents in contact.

### Characteristics:

|  |   |
|--|---|
| <b>It doesn't contain latex protein. Suitable for latex allergic people.</b> | <b>Raised diamond pattern for better sustained grip.</b>  |
| <b>Green. Available in bue.</b>  | <b>Flocklined.</b>  |
| <b>Resistance to oils and petroleum.</b>                                     | <b>Microbiological risks (bacteria, fungi and virus).</b> |
| <b>Silicone Free .</b>   | <b>Abrasion and resistance against certain chemicals.</b> |

### Packaging:

- Carton 144 pairs.
- Individual bag
- Packaging contains: 12 pack of 12 pcs.
- Dimension bag: 395 x 150 x 20 mm.



### Labelling:

Manufacturing date, expiration date, batch number, reference, and EAN code. Product name in several languages: Spanish, English, French, German, Italian, Portuguese, etc.

Ce marking, Protection Pictograms, Safety standars and legislation. Size and units, size guide.



| Glove Dimensions                  | S          | M          | L          | XL         | XXL        |
|-----------------------------------|------------|------------|------------|------------|------------|
| <b>Lenght</b>                     | Min 330 mm | Min 330 mm | Min 330 mm | Min 330 mm | Min 330 mm |
| <b>Palm Thickness mm (± 0.02)</b> | 0.40       | 0.40       | 0.40       | 0.40       | 0.40       |

RUBBEREX SPAIN S.L

+34 96 166 7124

[info@rubberex.es](mailto:info@rubberex.es)

[www.rubberex.es](http://www.rubberex.es)

Polígono Industrial Masía del Baló. C/Mas Vallesa de Mandor N8 Nave12. CP. 46190. Ribarroja del Turia. Valencia. España

## Regulations:

Regulation (EU) 2016/425. Personal protective equipment repealing Council Directive 89/686/EEC.

EN ISO 21420:2020

EN ISO 18889:2020

EN 388:2016+A1:2018. Protection against mechanical hazards.

A: Abrasion resistance (performance level 0 to 4).

B: Resistance to cutting by blade (performance level 0 to 5).

C: Resistance to tearing (performance level 0 to 4).

D: Puncture resistance (performance level 0 to 4)

E: Resistance to sharp cut (level A to F) X means not tested.

## Chemical resistance:

### PERMEATION EN 16523-1:2015. CHEMICAL HAZARDS EN ISO 374-1:2016+A1:2018

Gloves are classified in terms of breakthrough time, according to each individual chemical for which the glove resists permeation.

The gloves are tested against the following chemicals:

| CHEMICALS             | CODE | LEVEL |
|-----------------------|------|-------|
| METHANOL              | A    | 2     |
| N-HEPTANE             | J    | 6     |
| 40% SODIUM HIDROXIDE  | K    | 6     |
| 96% SULPHURIC ACID    | L    | 3     |
| 99% ACETIC ACID       | N    | 3     |
| 25% AMMONIA           | O    | 5     |
| 30% HYDROGEN PEROXIDE | P    | 6     |
| 37% FORMALDEHYDE      | T    | 6     |

| Time (min) | > 10 | > 30 | > 60 | > 120 | > 240 | > 480 |
|------------|------|------|------|-------|-------|-------|
| Level      | 1    | 2    | 3    | 4     | 5     | 6     |

EN 388: 2016+A1:2018

**G2 gloves**

EN ISO 374-1:2016+A1:2018/Type A

EN ISO 374-5:2016



4101X



ISO 18889



JKLOPT



VIRUS



CAT III



2777

## DEGRADATION EN 374-4:2019

RUBBEREX SPAIN S.L

+34 96 166 7124

[info@rubberex.es](mailto:info@rubberex.es)

[www.rubberex.es](http://www.rubberex.es)

Polígono Industrial Masía del Baló. C/Mas Vallesa de Mandor N8 Nave12. CP. 46190. Ribarroja del Turia. Valencia. España



Degradation % (DR) is determined for each chemical made in the permeation.

(DR) J : n-Heptane = 5.1%

(DR) K : Sodium Hydroxide 40% = -13,3%

(DR) L : Sulphuric Acid 96% = 61.8%

(DR) O : Ammonia 25% = -5.9%

(DR) P : Hydrogen Peroxide 30% = -5.2%

(DR) T : Formaldehyde 37% = -3.0%

The RNF15 PPE should be used to protect the user's hand against chemical risks (products mentioned above) and against microbiological risks (bacteria and fungi).

The present PPE should be used against other risks than those described above. The use of this PPE should be evaluated correctly depending on the place of work.

The performance levels stated for the gloves are based on tests carried out on the palm area of the glove. Before putting on gloves, make sure they are free of defects, punctures or tears. Discard the glove if it is punctured or torn during work.

| REFERENCE | COLOUR | SIZE NUMBER | SIZE     | EAN           |
|-----------|--------|-------------|----------|---------------|
| 0061      | GREEN  | 7           | SMALL    | 9556073212310 |
| 0062      | GREEN  | 8           | MEDIUM   | 9556073212327 |
| 0063      | GREEN  | 9           | LARGE    | 9556073212334 |
| 0064      | GREEN  | 10          | X-LARGE  | 9556073212341 |
| 0065      | GREEN  | 11          | XX-LARGE | 9556073212358 |

### Packing:



### Logistic:

Carton: 144 pairs

Pack: 12 pairs

Pallet: 40 cartons

REV.02 JUL 23

RUBBEREX SPAIN S.L

+34 96 166 7124

[info@rubberex.es](mailto:info@rubberex.es)

[www.rubberex.es](http://www.rubberex.es)

Polígono Industrial Masía del Baló. C/Mas Vallesa de Mandor N8 Nave12. CP. 46190. Ribarroja del Turia. Valencia. España