

LATEX

YELLOW

REF: VLX

S-XL

FLOCKLINED

Natural latex glove flocked inside. Recommended for hygiene and cleaning. Suitable for multiple uses.

Characteristics:

Not suitable for latex allergic people.	Inverted rhombus finish on palm and tips for easy grip.
Yellow.	Flocked.
Soft .	Flexibility and adaptability.

Packaging:

- Carton 144 pairs.
- Individual bag.
- Packaging contains: 12 pack of 12 pcs.
- Dimension bag: 250 x 135 x 20 mm.



Labelling:

Manufacturing date, expiration date, batch number, reference, and EAN code. Product name in several languages: Spanish, English, French, German, Italian, Portuguese, etc.

Ce marking, Protection Pictograms, Safety standards and legislation. Size and units, size guide.



Glove Dimensions	S	M	L	XL
LENGTH	Min 295 mm	Min 295 mm	Min 295 mm	Min 295 mm
Palm Thickness mm (± 0.02)	0.30	0.30	0.30	0.30

RUBBEREX SPAIN S.L

☎ +34 96 166 7124

✉ info@rubberex.eswww.rubberex.es

📍 Polígono Industrial Masía del Baló. C/Mas Vallesa de Mandor N8 Nave12. CP. 46190. Ribarroja del Turia. Valencia. España

Regulations:

Regulation (EU) 2016/425. Personal protective equipment repealing Council Directive 89/686/EEC.

EN ISO 21420:2020

EN 388:2016+A1:2018. Protection against mechanical hazards.

A: Abrasion resistance (performance level 0 to 4).

B: Resistance to cutting by blade (performance level 0 to 5).

C: Resistance to tearing (performance level 0 to 4).

D: Puncture resistance (performance level 0 to 4)

E: Resistance to sharp cut (level A to F) X means not tested.

Chemical resistance:

PERMEATION EN 16523-1:2015. CHEMICAL HAZARDS EN ISO 374-1:2016+A1:2018

Gloves are classified in terms of breakthrough time, according to each individual chemical for which the glove resists permeation.

The gloves are tested against the following chemicals:

CHEMICALS	CODE						LEVEL
SODIUM HYDROXIDE 40%	K						2

Time (min)	> 10	> 30	> 60	> 120	> 240	> 480
Level	1	2	3	4	5	6

DEGRADATION EN 374-4:2019

Degradation % (DR) is determined for each chemical made in the permeation.

(DR) K : Sodium Hydroxide 40% = 1.3 %

EN 388: 2016+A1:2018

EN ISO 374-1:2016+A1:2018/Type C

EN ISO 374-5:2016



1000X



K



CAT III

2777



RUBBEREX SPAIN S.L

The VLX PPE should be used to protect the user’s hand against chemical risks (products mentioned above) and against microbiological risks (bacteria and fungi).

The present PPE should be used against other risks than those described above. The use of this PPE should be evaluated correctly depending on the place of work.

The performance levels stated for the gloves are based on tests carried out on the palm area of the glove. Before putting on gloves, make sure they are free of defects, punctures or tears. Discard the glove if it is punctured or torn during work.

REFERENCE	COLOUR	SIZE NUMBER	SIZE	EAN
0598	YELLOW	7	SMALL	9556073127119
0599	YELLOW	8	MEDIUM	9556073127126
0600	YELLOW	9	LARGE	9556073127133
0601	YELLOW	10	X-LARGE	9556073127140

Packing:



Logistic:

Carton: 144 pairs

Pack: 12 pairs

Pallet: 40 cartons

RUBBEREX SPAIN S.L

+34 96 166 7124

info@rubberex.es

www.rubberex.es

Polígono Industrial Masía del Baló. C/Mas Vallesa de Mandor N8 Nave12. CP. 46190. Ribarroja del Turia. Valencia. España