



NITRILE	BLUE	REF: RNU9	S-XXL	SATIN LINE
----------------	-------------	------------------	--------------	-------------------

Unflocked acrylonitrile butadiene rubber. Excellent resistance against aromatic and petroleum solvents and animal fats. Dust free internal and external surface.

Characteristics:

Not suitable for latex allergic people.	Inverted rhombus finish on palm and tips for easy grip.
Blue. Unflocked PPE.	Satin Line.
Resistance to oils and fats.	Microbiological risks (bacteria, fungi and virus).

Packaging:

- Carton 144 pairs.
- Individual bag.
- Packaging contains: 12 pack of 12 pcs.
- Dimension bag: 250 x 140 x 20 mm.



Labelling:

Manufacturing date, expiration date, batch number, reference, and EAN code. Product name in several languages: Spanish, English, French, German, Italian, Portuguese, etc.

Ce marking, Protection Pictograms, Safety standards and legislation. Size and units, size guide.



Glove Dimensions	S	M	L	XL	XXL
LENGTH	Min 330 mm	Min 330 mm	Min 330 mm	Min 330 mm	Min 330 mm
Palm Thickness mm (± 0.02)	0.22	0.22	0.22	0.22	0.22

RUBBEREX SPAIN S.L

+34 96 166 7124

info@rubberex.es

www.rubberex.es

Polígono Industrial Masía del Baló. C/Mas Vallesa de Mandor N8 Nave12. CP. 46190. Ribarroja del Turia. Valencia. España



Regulations:

Regulation (EU) 2016/425. Personal protective equipment repealing Council Directive 89/686/EEC.

EN ISO 21420:2020.

EN 388:2016+A1:2018. Protection against mechanical hazards.

A: Abrasion resistance (performance level 0 to 4).

B: Resistance to cutting by blade (performance level 0 to 5).

C: Resistance to tearing (performance level 0 to 4).

D: Puncture resistance (performance level 0 to 4)

E: Resistance to sharp cut (level A to F) X means not tested.

Chemical resistance:

PERMEATION EN 16523-1:2015. CHEMICAL HAZARDS EN ISO 374-1:2016+A1:2018

Gloves are classified in terms of breakthrough time, according to each individual chemical for which the glove resists permeation.

The gloves are tested against the following chemicals:

CHEMICALS	CODE	LEVEL
METHANOL	A	1
SODIUM HYDROXIDE 40%	K	6
SULPHURIC ACID 96%	L	1
ACETIC ACID 99%	N	1
AMMONIA 25%	O	3
HYDROGEN PEROXIDE 30%	P	6
FORMALDEHYDE 37%	T	6

Time (min)	> 10	> 30	> 60	> 120	> 240	> 480
Level	1	2	3	4	5	6

DEGRADATION EN 374-4:2019

Degradation % (DR) is determined for each chemical made in the permeation.

(DR) K : Sodium Hydroxide 40% = -7.0%

(DR) L : Acid Sulphuric 96% = 99.7%

(DR) N : Acetic Acid 99% = 100%

(DR) O : Ammonia 25% = 31.06%

(DR) P : Hydrogen peroxide 30% = 16.9%

(DR) T : Formaldehyde 37% = 2.7%

RUBBEREX SPAIN S.L

+34 96 166 7124


info@rubberex.es

www.rubberex.es

Polígono Industrial Masía del Baló. C/Mas Vallesa de Mandor N8 Nave12. CP. 46190. Ribarroja del Turia. Valencia. España



EN 388: 2016+A1:2018



2101X

EN ISO 374-1:2016+A1:2018/Type B



KOPT

EN ISO 374-5:2016



The RNU9 PPE should be used to protect the user's hand against chemical risks (products mentioned above) and against microbiological risks (bacteria and fungi).

The present PPE should be used against other risks than those described above. The use of this PPE should be evaluated correctly depending on the place of work.

The performance levels stated for the gloves are based on tests carried out on the palm area of the glove. Before putting on gloves, make sure they are free of defects, punctures or tears. Discard the glove if it is punctured or torn during work.

REFERENCE	COLOUR	SIZE NUMBER	SIZE	EAN
0246	BLUE	S	7	9556073301915
0247	BLUE	M	8	9556073301922
0248	BLUE	L	9	9556073301939
0249	BLUE	XL	10	9556073301946
0309	BLUE	XXL	11	9556073301953

Packing:



Logistic:

Carton: 144 pairs

Pack: 12 pairs

Pallet: 48 cartons

RUBBEREX SPAIN S.L

REV.07 JUL 2023

+34 96 166 7124

info@rubberex.es

www.rubberex.es

Polígono Industrial Masía del Baló. C/Mas Vallesa de Mandor N8 Nave12. CP. 46190. Ribarroja del Turia. Valencia. España