

GENTLE TOUCH HQ BLACK NITRILE 7.0 GR



NITRILE

BLACK

NO DUST

S-XL

AMBIDEXTROUS

NON-STERILE

Comfortable glove. It offers protection against specific chemical hazards and sporadic contact solvents. Among its uses, industrial stands out for its high thickness, food, automotive, laboratory, hygiene and cleaning, hairdressing, tattoo artists, DIY, etc.

Features:

It does not contain latex protein, suitable for latex allergy sufferers.	Pesticide protection
Black, dust-free, single-use, ambidextrous.	High strength and durability. Extra thickness
Cuff with flange, spill protection.	Flexibility and adaptability.

Presentation:

- Dispenser box of 100 units, with die-cut opening for hygienic access to the glove.
- Packaging contains: 10 boxes of 100 units
- Dimension: 250 x 130 x 75 mm



Labelling: Expiry date, date of manufacture, batch number, reference, barcode. Product name in several languages: Spanish, English, French, German, Portuguese, Italian.

CE marking, protection pictograms, safety standards and legislation. Size and units, size guide.

Regulations:

- Category III. CE marked according to Regulation (EU) 2016/425
- Food regulation 10/2011 on plastic materials intended to come into contact with food
- EN ISO 374-1:2016/A1:2018. Point 7 EN 374-2. Point 5 of the EN374-4 standard. Method EN 16523-1:2015. Resistance to chemical permeability.
- EN ISO 374-5:2016. Requirements for risks of microorganisms. (fungi, viruses and bacteria)
- EN420:2003+A1:2009. EN ISO 21420:2020
- EN455-1-2-3-4
- EN ISO 18889. Category G1. Minimum risks and requirements for pesticide protection.
- This product is not classified as hazardous according to Regulation EC 1272/2009 of the European Parliament and of the Council.
- This product contains less than 0.1% substances of very high concern (SVHC) and does not contain substances included in Annex VII of Regulation 1907/2006 of the European Parliament and of the Council. (REACH)

RUBBEREX SPAIN S.L

+34 96 166 7124

info@rubberex.es

www.rubberex.es

Masía del Baló Industrial Estate. C/Mas Vallesa de Mandor N8 Nave12. CP. 46190. Ribarroja del Turia. Valencia. Spain

CHEMICAL RESISTANCE

PERMEATION. EN ISO 374-1:2016/ A1:2018

Gloves are classified in terms of passage time, depending on each individual chemical for which the glove resists permeation.

The gloves are tested against the following chemicals:

CHEMICALS	LEVEL	LYRICS
SODIUM HYDROXIDE 40%	6	K
N-HEPTANE	6	J
FORMALDEHYDE 37%	6	T
HYDROGEN PEROXIDE 30%	4	P

Performance levels:

Passage time (min)	> 10	> 30	> 60	> 120	> 240	> 480
Performance level	1	2	3	4	5	6

DEGRADATION

The % degradation (DR) is determined for each chemical made in the permeation.

(DR) J: n-Heptane = 34.4%

(DR) K: Sodium hydroxide 40% = -5.0%

(DR) P: Hydrogen Peroxide 30%: 13.2%

(DR) T: Formaldehyde 37% = 27.05%

The PPE type GENTLE TOUCH HQ NITRILE GLOVE should be used to protect the wearer's hand against chemical hazards (products and levels mentioned above) and against microbiological hazards (bacteria, fungi and viruses).

This PPE should never be used against risks other than those described above. The use of this PPE should be evaluated correctly depending on the workplace.

EN ISO 374-1:2016/ A1:2018 /
Type B

EN ISO 374-5:2016



J K P T



VIRUS



AQL
1,5



0161



ISO 18889
G1

CAT III

RUBBEREX SPAIN S.L

+34 96 166 7124

info@rubberex.es

www.rubberex.es

Masía del Baló Industrial Estate. C/Mas Vallesa de Mandor N8 Nave12. CP. 46190. Ribarroja del Turia. Valencia. Spain

GENTLE TOUCH HQ BLACK NITRILE 7.0 GR



Glove Dimensions	S	M	L	XL
PALM WIDTH	85 ± 5 mm	95 ± 5 mm	110 ± 5 mm	110 ± 5 mm
LENGTH	Min 240 mm	Min 240 mm	Min 240 mm	Min 240 mm
Palm thickness mm (± 0.02)	0.125	0.125	0.125	0.125
Finger thickness mm (± 0.02)	0.14	0.14	0.14	0.14
Cuff thickness mm (± 0.02)	0.08	0.08	0.08	0.08
Weight gr. (± 0.3)	6.8	7.0	7.3	7.5

REF	Color	Size	T. numerical	EAN 13	EAN 14 MASTER BOX
0201	Black	S	7	8435234502013	18435234502010
0202	Black	M	8	8435234502020	18435234502027
0203	Black	L	9	8435234502037	18435234502034
0204	Black	XL	10	8435234502044	18435234502041

Dispenser

250x75x130mm



Logistics:

Dispenser: 100 gloves

Box: 10 dispensers per box

Pallet: 56 boxes – 8 boxes,
layer. 7 heights



RUBBEREX SPAIN S.L

+34 96 166 7124

info@rubberex.es

www.rubberex.es

Masía del Baló Industrial Estate. C/Mas Vallesa de Mandor N8 Nave12. CP. 46190. Ribarroja del Turia. Valencia. Spain